



YAMAHA

OWNER'S MANUAL

why.

YH50

5XS-F8199-E0

Welcome to the Yamaha world of motorcycling!

As the owner of the YH50, you are benefiting from Yamaha's vast experience and newest technology regarding the design and manufacture of high-quality products, which have earned Yamaha a reputation for dependability.

Please take the time to read this manual thoroughly, so as to enjoy all advantages of your YH50. The owner's manual does not only instruct you in how to operate, inspect and maintain your scooter, but also in how to safeguard yourself and others from trouble and injury.

In addition, the many tips given in this manual will help keep your scooter in the best possible condition. If you have any further questions, do not hesitate to contact your Yamaha dealer.

The Yamaha team wishes you many safe and pleasant rides. So, remember to put safety first!

IMPORTANT MANUAL INFORMATION

Particularly important information is distinguished in this manual by the following notations:



The Safety Alert Symbol means **ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!**

⚠ WARNING

Failure to follow **WARNING** instructions could result in severe injury or death to the scooter operator, a bystander, or a person inspecting or repairing the scooter.

CAUTION:

A **CAUTION** indicates special precautions that must be taken to avoid damage to the scooter.

NOTE :

A **NOTE** provides key information to make procedures easier or clearer.

NOTE : _____

- This manual should be considered a permanent part of this scooter and should remain with it even if the scooter is subsequently sold.
 - Yamaha continually seeks advancements in product design and quality. Therefore, while this manual contains the most current product information available at the time of printing, there may be minor discrepancies between your scooter and this manual. If you have any questions concerning this manual, please consult your Yamaha dealer.
-

IMPORTANT MANUAL INFORMATION

EW000002

⚠ WARNING

PLEASE READ THIS MANUAL CAREFULLY AND COMPLETELY BEFORE OPERATING THIS SCOOTER.

EAUM0023

YH50
OWNER'S MANUAL
© 2003 by MBK INDUSTRIE
1st Edition, January 2003
All rights reserved
Any reprinting or unauthorized use
without the written permission of
MBK INDUSTRIE
is expressly prohibited.
Printed in France.

TABLE OF CONTENTS

1	GIVE SAFETY THE RIGHT OF WAY	1
2	DESCRIPTION	2
3	INSTRUMENT AND CONTROL FUNCTIONS	3
4	PRE-OPERATION CHECKS	4
5	OPERATION AND IMPORTANT RIDING POINTS	5
6	PERIODIC MAINTENANCE AND MINOR REPAIR	6
7	SCOOTER CARE AND STORAGE	7
8	SPECIFICATIONS	8
9	CONSUMER INFORMATION	9



GIVE SAFETY THE RIGHT OF WAY

GIVE SAFETY THE RIGHT OF WAY 1-1
Further safe-riding points 1-2



GIVE SAFETY THE RIGHT OF WAY

Scooters are fascinating vehicles, which can give you an unsurpassed feeling of power and freedom. However, they also impose certain limits, which you must accept; even the best scooter does not ignore the laws of physics.

Regular care and maintenance are essential for preserving value and operating condition of your scooter. Moreover, what is true for the scooter is also true for the rider: good performance depends on being in good shape. Riding under the influence of medication, drugs and alcohol is, of course, out of the question. Scooter riders—more than car drivers—must always be at their mental and physical best. Under the influence of even small amounts of alcohol, there is a tendency to take dangerous risks.

Protective clothing is as essential for the scooter rider as seat belts are for car drivers and passengers. Always wear a complete scooter suit (whether made of leather or tear-resistant synthetic materials with protectors), sturdy boots, scooter gloves and a properly fitting helmet. Optimum protective wear, however, should not encourage carelessness. Although full-coverage helmets and suits, in particular, create an illusion of total safety and protection, motorcyclists will always be vulnerable. Riders who lack critical self-control run the risk of going too fast and are apt to take chances. This is even more dangerous in wet weather. The good motorcyclist rides safely, predictably and defensively — avoiding all dangers, including those caused by others.

Enjoy your ride!



Further safe-riding points

- Be sure to signal clearly when making turns.
- Braking can be extremely difficult on a wet road. Avoid hard braking, because the scooter could slide. Apply the brakes slowly when stopping on a wet surface.
- Slow down as you approach a corner or turn. Once you have completed a turn, accelerate slowly.
- Be careful when passing parked cars. A driver might not see you and open a door in your path.
- Railroad crossings, streetcar rails, iron plates on road construction sites, and manhole covers become extremely slippery when wet. Slow down and cross them with caution. Keep the scooter upright, otherwise it could slide out from under you.
- The brake lining could get wet when you wash the scooter. After washing the scooter, check the brakes before riding.
- Always wear a helmet, gloves, trousers (tapered around the cuff and ankle so they do not flap), and a bright colored jacket.
- Do not carry too much luggage on the scooter. An overloaded scooter is unstable. Use a strong cord to secure any luggage to the carrier. A loose load will affect the stability of the scooter and could divert your attention from the road.


DESCRIPTION

Left view 2-1
Right view 2-2

DESCRIPTION

Left view

2




- 1. Rear brake lever
- 2. Fuel gauge
- 3. Speedometer
- 4. Main switch

(page 3-5, 6-12, 6-15)
(page 3-3)
(page 3-3)
(page 3-1, 3-8)

- 5. Final transmission oil filler cap (page 6-6)
- 6. Kick starter (page 3-7)
- 7. Air filter (page 6-7)

Right view



- 8. Rear carrier
- 9. Passenger seat
- 10. Throttle grip
- 11. Front brake lever

(page 3-9)
—
(page 6-9, 6-15)
(page 3-5, 6-12, 6-15)

- 12. Luggage hook
- 13. Battery / fuse
- 14. Fuel and oil tank cap


(page 3-9)
(page 6-18 — 6-19)
(page 3-5)

INSTRUMENT AND CONTROL FUNCTIONS

Main switch / steering lock	3-1
Indicator and warning lights	3-2
Speedometer unit	3-3
Fuel gauge	3-3
Handlebar switches	3-4
Front brake lever	3-5
Rear brake lever	3-5
Fuel and 2-stroke engine oil tank caps	3-5
Fuel	3-6
Catalytic converter	3-7
2-stroke engine oil	3-7
Kickstarter	3-7
Rider seat	3-8
Storage compartment	3-8
Carrier	3-9
Luggage hook	3-9

INSTRUMENT AND CONTROL FUNCTIONS

3



EAU00029

Main switch/steering lock

The main switch/steering lock controls the ignition and lighting systems, and is used to lock the steering. The various positions are described below.

ON “☺”

EAU04384

All electrical circuits are supplied with power, the taillight and meter lighting come on, and the engine can be started. The key cannot be removed.

NOTE :

The headlight comes on as soon as the engine is started.

EAU00038

OFF “☹”

All electrical systems are off. The key can be removed.

EAU04470

CHECK “⊙”

The 2-stroke engine oil level warning light should come on. See page 3-2 for an explanation of the engine oil level warning light.

EAU00040

LOCK “🔒”

The steering is locked, and all electrical systems are off. The key can be removed.

To lock the steering

1. Turn the handlebars all the way to the left.
2. Push the key in from the “☹” position, and then turn it to “🔒” while still pushing it.
3. Remove the key.

To unlock the steering


Push the key in, and then turn it to “☹” while still pushing it.

EW000016

⚠️ WARNING

Never turn the key to “☹” or “🔒” while the scooter is moving, otherwise the electrical systems will be switched off, which may result in loss of control or an accident. Make sure that the scooter is stopped before turning the key to “☹” or “🔒”.

INSTRUMENT AND CONTROL FUNCTIONS



1. Turn signal indicator light "↔"
2. High beam indicator light "≡"

EAU03034

Indicator and warning lights

EAU00057


Turn signal indicator light "↔"

This indicator light flashes when the turn signal switch is pushed to the left or right.

EAU00063

High beam indicator light "≡"

This indicator light comes on when the high beam of the headlight is switched on.



1. Oil level indicator light "⚠"

EAU02958

Oil level warning light "⚠"

This warning light comes on when the key is in the "⊙" position or when the oil level in the 2-stroke engine oil tank is low during operation. If the warning light comes on during operation, stop immediately and fill the oil tank with Yamalube 2 or equivalent 2-stroke engine oil of either JASO grade "FC" or ISO grades "EG-C" or "EG-D". The warning light should go off after the 2-stroke engine oil tank has been refilled.

NOTE : _____

If the warning light does not come on when the key is in the "⊙" position or does not go off after the 2-stroke engine oil tank has been refilled, have a Yamaha dealer check the electrical circuit.


EC000000

CAUTION: _____

Do not operate the scooter until you know that the engine oil level is sufficient.

INSTRUMENT AND CONTROL FUNCTIONS

3




1. Speedometer
2. Odometer

EAU00098

Speedometer unit

The speedometer unit is equipped with a speedometer and an odometer. The speedometer shows riding speed. The odometer shows the total distance traveled.



1. Fuel gauge

EAU00113


Fuel gauge

The fuel gauge indicates the amount of fuel in the fuel tank. The needle moves towards "E" (Empty) as the fuel level decreases. When the needle reaches "E", refuel as soon as possible.

NOTE : _____

Do not allow the fuel tank to empty itself completely.

INSTRUMENT AND CONTROL FUNCTIONS



1. Dimmer switch "☞ / ☜"
2. Cancel button
3. Turn signal switch "☞ / ☜"
4. Horn switch "📢"

Handlebar switches

EAU00118

Dimmer switch "☞ / ☜"


EAU03888

Set this switch to "☞" for the high beam and to "☜" for the low beam.

Turn signal switch "☞ / ☜"

EAU00097

To signal a right-hand turn, push this switch to "☞". To signal a left-hand turn, push this switch to "☜". When released, the switch returns to the center position. To turn off the turn signal lights, push the cancel button, and then release it.



1. Start switch "🔌"

Horn switch "📢"

EAU00129

Press this switch to sound the horn.

Start switch "🔌"

EAU00063

Push this switch while applying the front or rear brake to crank the engine with the starter.


EC000005

CAUTION:


See page 5-1 for starting instructions prior to starting the engine.

INSTRUMENT AND CONTROL FUNCTIONS


3



1. Front brake lever



1. Rear brake lever



1. Oil tank cap
2. Fuel tank cap

Front brake lever

EAU03882

The front brake lever is located on the right handlebar grip. To apply the front brake, pull this lever toward the handlebar grip.

Rear brake lever

EAU00163

The rear brake lever is located on the left handlebar grip. To apply the rear brake, pull this lever toward the handlebar grip.

Fuel and 2-stroke engine oil tank caps

EAU03463

The fuel tank cap and the 2-stroke engine oil tank cap are located under the seat. (See page 3-8 for seat opening and closing procedures.)

Fuel tank cap

To remove the fuel tank cap, turn it counterclockwise, and then pull it off. To install the fuel tank cap, turn it clockwise.

INSTRUMENT AND CONTROL FUNCTIONS


EAU00185
EC000008

CAUTION:

Immediately wipe off spilled fuel with a clean, dry, soft cloth, since fuel may deteriorate painted surfaces or plastic parts.

EAU04206

3



2-stroke engine oil tank cap


To remove the 2-stroke engine oil tank cap, pull it off.

To install the 2-stroke engine oil tank cap, push it into the oil tank opening.

⚠ WARNING

EW000025

Make sure that the fuel and 2-stroke engine oil tank caps are properly installed before riding the scooter.



1. Filler tube
2. Fuel level

EAU03753

Fuel

Make sure that there is sufficient fuel in the tank. Fill the fuel tank to the bottom of the filler tube as shown.

EW000130

⚠ WARNING

- Do not overfill the fuel tank, otherwise it may overflow when the fuel warms up and expands.
- Avoid spilling fuel on the hot engine.

Recommended fuel:
REGULAR UNLEADED
GASOLINE ONLY
Fuel tank capacity:
Total amount:
7.2 L

Your Yamaha engine has been designed to use regular unleaded gasoline with a research octane number of 91 or higher. If knocking (or pinging) occurs, use a gasoline of a different brand or premium unleaded fuel. Use of unleaded fuel will extend spark plug life and reduce maintenance costs.

INSTRUMENT AND CONTROL FUNCTIONS

Catalytic converter

EAU03098

This scooter is equipped with a catalytic converter in the muffler.

EW000128

⚠ WARNING

The exhaust system is hot after operation. Make sure that the exhaust system has cooled down before doing any maintenance work.

EC000114

CAUTION:

The following precautions must be observed to prevent a fire hazard or other damages.

- Use only unleaded gasoline. The use of leaded gasoline will cause unrepairable damage to the catalytic converter.
- Never park the scooter near possible fire hazards such as grass or other materials that easily burn.
- Do not allow the engine to idle too long.

2-stroke engine oil

EAU03750

Make sure that there is sufficient oil in the 2-stroke engine oil tank. Add the recommended 2-stroke engine oil if necessary.


NOTE :

Make sure that the 2-stroke engine oil tank cap is properly installed.

Recommended oil:

Yamalube 2 or equivalent
2-stroke engine oil
(JASO grade "FC",
or ISO grades "EG-C" or "EG-D")

Oil quantity:
1.3 L




1. Kickstarter

EAU0015

Kickstarter

To start the engine, push the kickstarter down lightly with your foot until the gears engage, and then push it down smoothly but forcefully.

INSTRUMENT AND CONTROL FUNCTIONS



EAU03091


Rider seat

To open the rider seat

1. Place the scooter on the centerstand.
2. Insert the key into the main switch, and then turn it counterclockwise.

NOTE : _____
Do not push inward when turning the key.


3. Fold the rider seat up.



To close the rider seat

1. Fold the rider seat down, and then push it down to lock it in place.
2. Remove the key from the main switch if the scooter will be left unattended.

NOTE : _____
Make sure that the seat is properly secured before riding.



EAU00096

Storage compartment

To unlock the storage compartment

Insert the key in the lock and turn it 1/4 turn clockwise.

To open the storage compartment when it is unlocked

Turn the knob 1/4 turn clockwise. The knob will return to its original position after released.

To close the storage compartment

Push the lid into the original position

To lock the storage compartment


Insert the key in the lock and turn it 1/4 turn counterclockwise, and then remove the key.

INSTRUMENT AND CONTROL FUNCTIONS

⚠ WARNING

EWA00005

- Do not exceed the load limit of 1.5 kg for the storage compartment.
- Do not exceed the maximum load of 182 kg for the vehicle.



1. Carrier


Carrier

EAU00320

⚠ WARNING

EW000032

- Do not exceed the load limit of 3.0 kg for the carrier.
- Do not exceed the maximum load of 182 kg for the vehicle.



1. Luggage hook

Luggage hook

EAUT0020

⚠ WARNING

EWAT0002

- Do not exceed the load limit of 3.0 kg for the luggage hook.
- Do not exceed the maximum load of 182 kg for the vehicle.

PRE-OPERATION CHECKS

Pre-operation check list 4-1

PRE-OPERATION CHECKS

The condition of a vehicle is the owner's responsibility. Vital components can start to deteriorate quickly and unexpectedly, even if the vehicle remains unused (for example, as a result of exposure to the elements). Any damage, fluid leakage or loss of tire air pressure could have serious consequences. Therefore, it is very important, in addition to a thorough visual inspection, to check the following points before each ride.

EAU03439

Pre-operation check list

ITEM	CHECKS	PAGE
Fuel	<ul style="list-style-type: none">• Check fuel level in fuel tank.• Refuel if necessary.• Check fuel line for leakage.	3-5 — 3-6
2-stroke engine oil	<ul style="list-style-type: none">• Check oil level in oil tank.• If necessary, add recommended oil to specified level.• Check vehicle for oil leakage.	3-5 — 3-7
Final transmission oil	<ul style="list-style-type: none">• Check vehicle for oil leakage.	6-6
Front brake	<ul style="list-style-type: none">• Check operation.• If soft or spongy, have Yamaha dealer bleed hydraulic system.• Check fluid level in reservoir.• If necessary, add recommended brake fluid to specified level.• Check hydraulic system for leakage.	3-5, 6-13 — 6-15
Rear brake	<ul style="list-style-type: none">• Check operation.• Check pedal free play.• Adjust if necessary.	3-5, 6-13 — 6-15
Throttle grip	<ul style="list-style-type: none">• Make sure that operation is smooth.• Check cable free play.• If necessary, have Yamaha dealer adjust cable free play and lubricate cable and grip housing.	6-9, 6-15

PRE-OPERATION CHECKS

ITEM	CHECKS	PAGE
Wheels and tires	<ul style="list-style-type: none">• Check for damage.• Check tire condition and tread depth.• Check air pressure.• Correct if necessary.	6-10 — 6-11
Brake levers	<ul style="list-style-type: none">• Make sure that operation is smooth.• Lubricate lever pivoting points if necessary.	6-12, 6-15
Centerstand	<ul style="list-style-type: none">• Make sure that operation is smooth.• Lubricate pivot if necessary.	6-16
Chassis fasteners	<ul style="list-style-type: none">• Make sure that all nuts, bolts and screws are properly tightened.• Tighten if necessary.	—
Instruments, lights, signals and switch	<ul style="list-style-type: none">• Check operation.• Correct if necessary.	3-2 — 3-4
Battery	<ul style="list-style-type: none">• Check fluid level.• Fill with distilled water if necessary.	6-18

NOTE : _____
Pre-operation checks should be made each time the scooter is used. Such an inspection can be accomplished in a very short time; and the added safety it assures is more than worth the time involved.

⚠ WARNING

EWA00033

If any item in the Pre-operation check list is not working properly, have it inspected and repaired before operating the scooter.

OPERATION AND IMPORTANT RIDING POINTS


Starting the engine	5-1
Starting off.....	5-2
Acceleration and deceleration	5-2
Braking	5-3
Tips for reducing fuel consumption	5-3
Engine break-in	5-4
Parking	5-4

OPERATION AND IMPORTANT RIDING POINTS

EAU01118
EW000129

⚠️ WARNING

- Become thoroughly familiar with all operating controls and their functions before riding. Consult a Yamaha dealer regarding any control or function that you do not thoroughly understand.
- Never start the engine or operate it in a closed area for any length of time. Exhaust fumes are poisonous, and inhaling them can cause loss of consciousness and death within a short time. Always make sure that there is adequate ventilation.
- For safety, always start the engine with the centerstand down.



EAU02960

Starting the engine

EC000046

CAUTION:

See page 5-4 for engine break-in instructions prior to operating the vehicle for the first time.


1. Turn the key to "●", and when the oil level warning light comes on, turn it to "⊙".

EC000045

CAUTION:

If the oil level warning light does not come on, have a Yamaha dealer check the electrical circuit.

2. Close the throttle completely.



3. While applying the front or rear brake, start the engine by pushing the start switch or by pushing the kickstarter lever down.

NOTE :


If the engine fails to start by pushing the start switch, release the switch, wait a few seconds, and then try again. Each starting attempt should be as short as possible to preserve the battery. Do not crank the engine more than 5 seconds on any one attempt. If the engine does not start with the starter motor, try using the kickstarter.

OPERATION AND IMPORTANT RIDING POINTS

CAUTION:

ECA00045

For maximum engine life, never accelerate hard when the engine is cold!




EAU04473

Starting off

NOTE :

Before starting off, allow the engine to warm up.

1. While pulling the rear brake lever with your left hand and holding the carrier with your right hand, push the scooter off the centerstand.
2. Sit astride the seat, and then adjust the rear view mirrors.
3. Switch the turn signal on.
4. Check for oncoming traffic, and then slowly turn the throttle grip (on the right) in order to take off.
5. Switch the turn signal off.




EAU00434

Acceleration and deceleration

The speed can be adjusted by opening and closing the throttle. To increase the speed, turn the throttle grip in direction **a**. To reduce the speed, turn the throttle grip in direction **b**.

OPERATION AND IMPORTANT RIDING POINTS



EAU00435

Braking

1. Close the throttle completely.
2. Apply both front and rear brakes simultaneously while gradually increasing the pressure.

⚠ WARNING

EW000057

- **Avoid braking hard or suddenly (especially when leaning over to one side), otherwise the scooter may skid or overturn.**

- **Railroad crossings, streetcar rails, iron plates on road construction sites, and manhole covers become extremely slippery when wet. Therefore, slow down when approaching such areas and cross them with caution.**
- **Keep in mind that braking on a wet road is much more difficult. Ride slowly down a hill, as braking downhill can be very difficult.**

EAU03093

Tips for reducing fuel consumption

Fuel consumption depends largely on your riding style. Consider the following tips to reduce fuel consumption:

- Thoroughly warm up the engine. Avoid high engine speeds during acceleration.
- Avoid high engine speeds with no load on the engine.
- Turn the engine off instead of letting it idle for an extended length of time (e.g., in traffic jams, at traffic lights or at railroad crossings).

OPERATION AND IMPORTANT RIDING POINTS

Engine break-in

EAU00436

There is never a more important period in the life of your engine than the period between 0 and 1,000 km. For this reason, you should read the following material carefully.

Since the engine is brand new, do not put an excessive load on it for the first 1,000 km. The various parts in the engine wear and polish themselves to the correct operating clearances. During this period, prolonged full-throttle operation or any condition that might result in engine overheating must be avoided.

0 — 150 km

EAUT0003*

Avoid operation above 1/3 throttle. Stop the engine and let it cool for 5 to 10 minutes after every hour of operation. Vary the speed of the scooter from time to time. Do not operate it at one set throttle position.

150 — 500 km

Avoid prolonged operation above 1/2 throttle.

500 — 1,000 km

Avoid cruising speeds in excess of 3/4 throttle.

CAUTION:

ECAT0001

After 1,000 km of operation, be sure to replace the final transmission oil.

1,000 km and beyond

Avoid prolonged full throttle operation. Vary speeds occasionally.

CAUTION:

EC000049

If any engine trouble should occur during the engine break-in period, immediately have a Yamaha dealer check the vehicle.

EAU00461

Parking

When parking, stop the engine, and then remove the key from the main switch.

▲ WARNING

EW000058

- Since the engine and exhaust system can become very hot, park in a place where pedestrians or children are not likely to touch them.
- Do not park on a slope or on soft ground, otherwise the scooter may overturn.

CAUTION:

EC000062

Never park in an area where there are fire hazards such as grass or other flammable materials.

PERIODIC MAINTENANCE AND MINOR REPAIR

Periodic maintenance and lubrication chart	6-2	Changing the brake fluid	6-15
Removing and installing the panel	6-5	Checking and lubricating the throttle grip	6-15
Panel A	6-5	and cable	
Checking the spark plug	6-5	Lubricating the front and rear brakes levers	6-15
Final transmission oil	6-6	Checking and lubricating the centerstand	6-16
Cleaning the air filter element	6-7	Checking the front fork	6-16
Adjusting the carburetor	6-9	Checking the steering	6-17
Adjusting the throttle cable free play	6-9	Checking the wheel bearings	6-17
Tires	6-10	Battery	6-18
Cast wheels	6-11	Replacing the fuse	6-19
Adjusting the front brake lever free play	6-12	Replacing a headlight bulb	6-20
Adjusting the front brake lever free play	6-12	Replacing the brake taillight bulb	6-21
Checking the front brake pads	6-13	Replacing a turn signal light bulb	6-21
and rear brake shoes		Troubleshooting	6-22
Checking the brake fluid level	6-14	Troubleshooting chart	6-23

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU03453

Safety is an obligation of the owner. Periodic inspection, adjustment and lubrication will keep your vehicle in the safest and most efficient condition possible. The most important points of scooter inspection, adjustment, and lubrication are explained on the following pages.

EAU00466
EW000061

⚠ WARNING

This scooter is designed for use on paved roads only. If this scooter is operated in abnormally dusty, muddy or wet conditions, the air filter element should be cleaned or replaced more frequently, otherwise rapid engine wear may result. Consult a Yamaha dealer for proper maintenance intervals.

EW000060

⚠ WARNING

If you are not familiar with scooter maintenance work, have a Yamaha dealer do it for you.

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU03686

Periodic maintenance and lubrication chart

NOTE :

- The annual checks must be performed every year, except if a kilometer-based maintenance is performed instead.
- From 30,000 km, repeat the maintenance intervals starting from 6,000 km.
- Items marked with an asterisk should be performed by a Yamaha dealer as they require special tools, data and technical skills.

NO.	ITEM	CHECK OR MAINTENANCE JOB	ODOMETER READING (x 1,000 km)					ANNUAL CHECK
			1	6	12	18	24	
1	* Fuel line	• Check fuel hoses and vacuum hose for cracks or damage.		√	√	√	√	√
2	Spark plug	• Replace.		√	√	√	√	√
3	Air filter element	• Clean.		√		√		
		• Replace.			√		√	
4	* Battery	• Check electrolyte level and specific gravity. • Make sure that the breather hose is properly routed.		√	√	√	√	√
5	* Front brake	• Check operation, fluid level and vehicle for fluid leak (See NOTE on page 6-4.)	√	√	√	√	√	√
		• Replace brake pads.	Whenever worn to the limit					
6	* Rear brake	• Check operation and adjust brake lever free play.	√	√	√	√	√	√
		• Replace brake shoes.	Whenever worn to the limit					
7	* Brake hose	• Check for cracks or damage.		√	√	√	√	√
		• Replace. (See NOTE on page 6-4.)	Every 4 years					
8	* Wheels	• Check runout and for damage.		√	√	√	√	

PERIODIC MAINTENANCE AND MINOR REPAIR

NO.	ITEM	CHECK OR MAINTENANCE JOB	ODOMETER READING (x 1,000 km)					ANNUAL CHECK
			1	6	12	18	24	
9	* Tires	<ul style="list-style-type: none"> • Check tread depth and for damage. • Replace if necessary. • Check air pressure. • Correct if necessary. 		√	√	√	√	√
10	* Wheel bearings	<ul style="list-style-type: none"> • Check bearing for looseness or damage. 		√	√	√	√	
11	* Steering bearings	<ul style="list-style-type: none"> • Check bearing play and steering for roughness. 	√	√	√	√	√	
		<ul style="list-style-type: none"> • Lubricate with lithium-soap-based grease. 	Every 24,000 km					
12	* Chassis fasteners	<ul style="list-style-type: none"> • Make sure that all nuts, bolts and screws are properly tightened. 		√	√	√	√	√
13	Centerstand	<ul style="list-style-type: none"> • Check operation. • Lubricate. 		√	√	√	√	√
14	* Front fork	<ul style="list-style-type: none"> • Check operation and for oil leakage. 		√	√	√	√	
15	* Shock absorber assembly	<ul style="list-style-type: none"> • Check operation and shock absorber for oil leakage. 		√	√	√	√	
16	* Carburetor	<ul style="list-style-type: none"> • Adjust engine idling speed. 	√	√	√	√	√	√
17	* Autolube pump	<ul style="list-style-type: none"> • Check operation. • Bleed if necessary. 	√		√		√	√
18	Final transmission oil	<ul style="list-style-type: none"> • Check vehicle for oil leakage. 	√	√		√		
		<ul style="list-style-type: none"> • Change. 	√		√		√	
19	* V-belt	<ul style="list-style-type: none"> • Replace. 	Every 10,000 km					
20	* Front and rear brake switches	<ul style="list-style-type: none"> • Check operation. 	√	√	√	√	√	√

PERIODIC MAINTENANCE AND MINOR REPAIR


NO.	ITEM	CHECK OR MAINTENANCE JOB	ODOMETER READING (x 1,000 km)					ANNUAL CHECK
			1	6	12	18	24	
21	Moving parts and cables	• Lubricate.		√	√	√	√	√
22	* Lights, signals and switches	• Check operation. • Adjust headlight beam.	√	√	√	√	√	√

EAU03541*

NOTE :

- The air filter needs more frequent service if you are riding in unusually wet or dusty areas.
- Hydraulic brake service
 - Regularly check and, if necessary, correct the brake fluid level.
 - Every two years change the brake fluid.
 - Replace the brake hoses every four years and if cracked or damaged.

PERIODIC MAINTENANCE AND MINOR REPAIR




1. Panel A

Removing and installing the panel

EAU01777

The panel shown above needs to be removed to perform some of the maintenance jobs described in this chapter. Refer to this section each time the panel needs to be removed and installed.



Panel A

EAU00095

To remove the panel

1. Open the seat. (See page 3-8 for seat opening and closing procedures.)
2. Remove the panel by pulling it up as shown.

To install the panel

1. Insert the rear of the panel in the original position, and then push the front of the panel inward..
2. Close the seat.

EAU01651


Checking the spark plug

The spark plug is an important engine component, which should be checked periodically, preferably by a Yamaha dealer. Since heat and deposits will cause any spark plug to slowly erode, it should be removed and checked in accordance with the periodic maintenance and lubrication chart. In addition, the condition of the spark plug can reveal the condition of the engine.

The porcelain insulator around the center electrode of the spark plug should be a medium-to-light tan (the ideal color when the scooter is ridden normally). If the spark plug shows a distinctly different color, the engine could be defective. Do not attempt to diagnose such problems yourself. Instead, have a Yamaha dealer check the scooter.

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU04228



(a) Spark plug gap

If the spark plug shows signs of electrode erosion and excessive carbon or other deposits, it should be replaced.

Specified spark plug:
BR8HS (NGK)

Before installing a spark plug, the spark plug gap should be measured with a wire thickness gauge and, if necessary, adjusted to specification.

Spark plug gap:
0.6 — 0.7 mm

Clean the surface of the spark plug gasket and its mating surface, and then wipe off any grime from the spark plug threads.

Tightening torque:
Spark plug:
23 Nm (2.3 m·kg)


NOTE : _____
If a torque wrench is not available when installing a spark plug, a good estimate of the correct torque is 1/4 — 1/2 turn past finger tight. However, the spark plug should be tightened to the specified torque as soon as possible.

Final transmission oil

The final transmission case must be checked for oil leakage before each ride. If any leakage is found, have a Yamaha dealer check and repair the scooter. In addition, the final transmission oil must be changed as follows at the intervals specified in the periodic maintenance and lubrication chart.

1. Start the engine, warm it up by riding the scooter for several minutes, and then stop the engine.
2. Place the scooter on the centerstand.
3. Place an oil pan under the final transmission case to collect the used oil.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Oil filler cap
2. Oil drain bolt

4. Remove the oil filler cap and drain bolt to drain the oil from the final transmission case.
5. Install the final transmission oil drain bolt, and then tighten it to the specified torque.

Tightening torque:

Final transmission oil drain bolt:
17 Nm (1.7 m.kg)

6. Add the specified amount of the recommended final transmission oil, and then install and tighten the oil filler cap.


Recommended final transmission oil:
See page 8-1.
Oil quantity:
0.11 L

⚠ WARNING

EWA00062

- **Make sure that no foreign material enters the final transmission case.**
- **Make sure that no oil gets on the tire or wheel.**

7. Check the final transmission case for oil leakage. If oil is leaking, check for the cause.



1. Screws


EALUM0071

Cleaning the air filter element

The air filter element should be cleaned at the intervals specified in the periodic maintenance and lubrication chart. Clean the air filter element more frequently if you are riding in unusually wet or dusty areas.

1. Remove the air filter case cover by removing the screws.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Air filter element

2. Pull the air filter element out, clean it with solvent, and then squeeze the remaining solvent out.

⚠ WARNING


EW000075

Use only a dedicated parts cleaning solvent. To avoid the risk of fire or explosion, do not use gasoline or solvents with a low flash point.

CAUTION:

EC000089

To avoid damaging the foam material, handle it gently and carefully, and do not twist or wring it.



3. Apply oil of the recommended type to the entire surface of the element, and then squeeze the excess oil out.

NOTE :

The air filter element should be wet but not dripping

Recommended oil:
Engine oil

4. Insert the element into the air filter case.

CAUTION:

EC000082

- Make sure that the air filter element is properly seated in the air filter case.
- The engine should never be operated without the air filter element installed, otherwise the piston(s) and/or cylinder(s) may become excessively worn.


5. Install the air filter case cover by installing the screws.

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU00631

Adjusting the carburetor

The carburetor is an important part of the engine and requires very sophisticated adjustment. Therefore, all carburetor adjustments should be left to a Yamaha dealer, who has the necessary professional knowledge and experience.




Ⓐ Throttle cable free play

EAU00635

Adjusting the throttle cable free play

The throttle cable free play should measure 1.5 — 3.0 mm at the throttle grip. Periodically check the throttle cable free play and, if necessary, have a Yamaha dealer adjust it.

PERIODIC MAINTENANCE AND MINOR REPAIR



ZAJM0053

EAU04551

Tires

To maximize the performance, durability, and safe operation of your scooter, note the following points regarding the specified tires.

Tire air pressure

The tire air pressure should be checked and, if necessary, adjusted before each ride.

⚠ WARNING

EW000082

- The tire air pressure must be checked and adjusted on cold tires (i.e., when the temperature of the tires equals the ambient temperature).
- The tire air pressure must be adjusted in accordance with the riding speed and with the total weight of rider, passenger, cargo, and accessories approved for this model.

Tire air pressure (measured on cold tires)		
Load*	Front	Rear
Up to 90 kg*	180 kPa 1.8 kgf/cm ² 1.8 bar	190 kPa 1.9 kgf/cm ² 1.9 bar
90 kg ~ maximum*	180 kPa 1.8 kgf/cm ² 1.8 bar	210 kPa 2.1 kgf/cm ² 2.1 bar

Maximum load*	182 kg
---------------	--------

* Total weight of rider, passenger, cargo and accessories

⚠ WARNING


EW000077

Because loading has an enormous impact on the handling, braking, performance and safety characteristics of your scooter, you should keep the following precautions in mind.

- **NEVER OVERLOAD THE SCOOTER!** Operation of an overloaded scooter may result in tire damage, loss of control, or severe injury. Make sure that the total weight of rider, cargo, and accessories does not exceed the specified maximum load for the vehicle.
- Do not carry along loosely packed items, which can shift during a ride.
- Securely pack the heaviest items close to the center of the scooter and distribute the weight evenly on both sides.
- Adjust the suspension and tire air pressure with regard to the load.
- Check the tire condition and air pressure before each ride.

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU03773



1. Tire tread depth
2. Tire sidewall

Tire inspection

The tires must be checked before each ride. If the center tread depth reaches the specified limit, if the tire has a nail or glass fragments in it, or if the sidewall is cracked, have a Yamaha dealer replace the tire immediately.

Minimum tire tread depth (front and rear)	1.6 mm
--	--------

NOTE : _____
The tire tread depth limits may differ from country to country. Always comply with the local regulations.

Tire information

This scooter is equipped with tubeless tires.

Front

Manufacturer	Size	Type
MICHELIN	2 1/2 -16 42M	M29S TT

Rear


Manufacturer	Size	Type
MICHELIN	2 3/4 -16 46M	M29S TT

Cast wheels

To maximize the performance, durability, and safe operation of your scooter, note the following points regarding the specified wheels.

- The wheel rims should be checked for cracks, bends or warpage before each ride. If any damage is found, have a Yamaha dealer replace the wheel. Do not attempt even the smallest repair to the wheel. A deformed or cracked wheel must be replaced.
- The wheel should be balanced whenever either the tire or wheel has been changed or replaced. An unbalanced wheel can result in poor performance, adverse handling characteristics, and a shortened tire life.
- Ride at moderate speeds after changing a tire since the tire surface must first be "broken in" for it to develop its optimal characteristics.

PERIODIC MAINTENANCE AND MINOR REPAIR



Ⓐ Front brake lever free play

EAU00697*


Adjusting the front brake lever free play

The brake lever free play should measure 10—20 mm as shown. Periodically check the brake lever free play and, if necessary, have a Yamaha dealer adjust it.

EW000100

⚠ WARNING

An incorrect brake lever free play indicates a hazardous condition in the brake system. Do not operate the scooter until the brake system has been checked or repaired by a Yamaha dealer.




Ⓐ Rear brake lever free play

EAU04469

Adjusting the rear brake lever free play

The brake lever free play should measure 10—20 mm as shown. Periodically check the brake lever free play and, if necessary, adjust it as follows.



1. Adjusting nut

To increase the brake lever free play, turn the adjusting nut at the brake shoe plate in direction Ⓐ. To decrease the brake lever free play, turn the adjusting nut in direction Ⓑ.

⚠ WARNING

EW000101


If proper adjustment cannot be obtained as described, have a Yamaha dealer make this adjustment.

PERIODIC MAINTENANCE AND MINOR REPAIR

Checking the front brake pads and rear brake shoes

EAU00720

The front brake pads and the rear brake shoes must be checked for wear at the intervals specified in the periodic maintenance and lubrication chart.




(a) Lining thickness

EAU01436

Front brake pads

Check each front brake pad for damage and measure the lining thickness. If a brake pad is damaged or if the lining thickness is less than 0.5 mm, have a Yamaha dealer replace the brake pads as a set.




1. Wear indicator
2. Wear limit

EAU04502

Rear brake shoes

The rear brake is provided with a wear indicator, which allows you to check the brake shoe wear without having to disassemble the brake. To check the brake shoe wear, check the position of the wear indicator while applying the brake. If a brake shoe has worn to the point that the wear indicator reaches the wear limit line, have a Yamaha dealer replace the brake shoes as a set.



1. Brake fluid level

Checking the brake fluid level

EAU00732

Insufficient brake fluid may allow air to enter the brake system, possibly causing it to become ineffective.

Before riding, check that the brake fluid is above the minimum level mark and replenish if necessary. A low brake fluid level may indicate worn brake pads and/or brake system leakage. If the brake level is low, be sure to check the brake pads for wear and the brake system for leakage.

Observe these precautions:

- When checking the fluid level, make sure that the top of the master cylinder is level by turning the handlebars.
- Use only the recommended quality brake fluid, otherwise the rubber seals may deteriorate, causing leakage and poor braking performance.

Recommended brake fluid:
DOT 4

NOTE : _____
If DOT 4 is not available, DOT 3 can be used.

- Refill with the same type of brake fluid. Mixing fluids may result in a harmful chemical reaction and lead to poor braking performance.

- Be careful that water does not enter the master cylinder when refilling. Water will significantly lower the boiling point of the fluid and may result in vapor lock.
- Brake fluid may deteriorate painted surfaces or plastic parts. Always clean up spilled fluid immediately.
- As the brake pads wear, it is normal for the brake fluid level to gradually go down. However, if the brake fluid level goes down suddenly, have a Yamaha dealer check the cause.

PERIODIC MAINTENANCE AND MINOR REPAIR

Changing the brake fluid

EAU00008

Have a Yamaha dealer change the brake fluid at the intervals specified in the periodic maintenance and lubrication chart. In addition, have the brake hose replaced every four years or whenever it is damaged or leaking.

Adjusting the Autolube pump


EAU00774

The Autolube pump is a vital and sophisticated component of the engine, which must be adjusted by a Yamaha dealer at the intervals specified in the periodic maintenance and lubrication chart.

Checking and lubricating the throttle grip and cable

EAU04034

The operation of the throttle grip should be checked before each ride. In addition, the cable should be lubricated or replaced at the intervals specified in the periodic maintenance chart.




Lubricating the front and rear brake levers

EAU03118

The pivoting points of the front and rear brake levers must be lubricated at the intervals specified in the periodic maintenance and lubrication chart.

Recommended lubricant:
Lithium-soap-based grease
(all-purpose grease)

PERIODIC MAINTENANCE AND MINOR REPAIR



EAU04123

Checking and lubricating the centerstand


The operation of the centerstand should be checked before each ride, and the pivots and metal-to-metal contact surfaces should be lubricated if necessary.

⚠ WARNING

EWA00055

If the centerstand does not move up and down smoothly, have a Yamaha dealer check or repair it.

Recommended lubricant:
Lithium-soap-based grease
(all-purpose grease)



EAU02939

Checking the front fork

The condition and operation of the front fork must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.

To check the condition

EW000115

⚠ WARNING

Securely support the scooter so that there is no danger of it falling over.

Check the inner tubes for scratches, damage and excessive oil leakage.

To check the operation


1. Place the scooter on a level surface and hold it in an upright position.
2. While applying the front brake, push down hard on the handlebars several times to check if the front fork compresses and rebounds smoothly.

CAUTION:

EC000098

If any damage is found or the front fork does not operate smoothly, have a Yamaha dealer check or repair it.

PERIODIC MAINTENANCE AND MINOR REPAIR



EAU00794

Checking the steering

Worn or loose steering bearings may cause danger. Therefore, the operation of the steering must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.

1. Place a stand under the engine to raise the front wheel off the ground.

EW000115

⚠ WARNING

Securely support the scooter so that there is no danger of it falling over.

2. Hold the lower ends of the front fork legs and try to move them forward and backward. If any free play can be felt, have a Yamaha dealer check or repair the steering.

EAU01144

Checking the wheel bearings

The front and rear wheel bearings must be checked at the intervals specified in the periodic maintenance and lubrication chart. If there is play in the wheel hub or if the wheel does not turn smoothly, have a Yamaha dealer check the wheel bearings.

PERIODIC MAINTENANCE AND MINOR REPAIR

EAUM0049

Battery


A poorly maintained battery will corrode and discharge quickly. The electrolyte level, battery lead connections and breather hose routing should be checked before each ride and at the intervals specified in the periodic maintenance and lubrication chart.

To check the electrolyte level

1. Place the scooter on a level surface and hold it in an upright position.

NOTE : _____
Make sure that the scooter is positioned straight up when checking the electrolyte level.

2. Remove panel A. (See page 6-5 for panel removal and installation procedures.)



1. Maximum level mark
2. Minimum level mark

3. Check the electrolyte level in the battery.

NOTE : _____
The electrolyte should be between the minimum and maximum level marks.

4. If the electrolyte is at or below the minimum level mark, add distilled water to raise it to the maximum level mark.

⚠ WARNING

EW000116

- Electrolyte is poisonous and dangerous since it contains sulfuric acid, which causes severe burns. Avoid any contact with skin, eyes or clothing and always shield your eyes when working near batteries. In case of contact, administer the following FIRST AID.
- **EXTERNAL:** Flush with plenty of water.
- **INTERNAL:** Drink large quantities of water or milk and immediately call a physician.
- **EYES:** Flush with water for 15 minutes and seek prompt medical attention.
- Batteries produce explosive hydrogen gas. Therefore, keep sparks, flames, cigarettes, etc., away from the battery and provide sufficient ventilation when charging it in an enclosed space.

PERIODIC MAINTENANCE AND MINOR REPAIR

- **KEEP THIS AND ALL BATTERIES OUT OF THE REACH OF CHILDREN.**

CAUTION:

EC000100

Use only distilled water, as tap water contains minerals that are harmful to the battery.


5. Check and, if necessary, tighten the battery lead connections and correct the breather hose routing.

4. After installation, make sure that the battery leads are properly connected to the battery terminals and that the breather hose is properly routed, in good condition, and not obstructed.

CAUTION:

EC000099

If the breather hose is positioned in such a way that the frame is exposed to electrolyte or gas expelled from the battery, the frame could suffer structural and external damages.



1. Fuse

EAU00809

Replacing the fuse

The fuse holder is located beside the battery compartment behind panel A. (See page 6-5 for panel removal and installation procedures.)

If the fuse is blown, replace it as follows.

1. Turn the key to "OFF" and turn off all electrical circuits.
2. Remove the blown fuse, and then install a new fuse of the specified amperage.

Specified fuse:
7.5 A

6

To store the battery

1. If the scooter will not be used for more than one month, remove the battery, fully charge it, and then place it in a cool, dry place.
2. If the battery will be stored for more than two months, check the specific gravity of the electrolyte at least once a month and fully charge the battery whenever necessary.
3. Fully charge the battery before installation.


PERIODIC MAINTENANCE AND MINOR REPAIR

CAUTION:

EC000103

Do not use a fuse of a higher amperage rating than recommended to avoid causing extensive damage to the electrical system and possibly a fire.

3. Turn the key to "O" and turn on the electrical circuits to check if the devices operate.
4. If the fuse immediately blows again, have a Yamaha dealer check the electrical system.



1. Headlight bulb holder

EAU00846

Replacing the headlight bulb

If the headlight bulb burns out, replace it as follows.

1. Remove the headlight unit by removing the screws.
2. Disconnect the headlight lead connectors.
3. Remove the headlight bulb holder by pushing it inward and turning it counterclockwise, and then remove the defective bulb.


WARNING

EW000119

Headlight bulbs get very hot. Therefore, keep flammable products away from a lit headlight bulb, and do not touch the bulb until it has cooled down.

4. Place a new bulb into position, and then secure it with the bulb holder.
5. Connect the lead connectors, and then install the headlight unit by installing the screws.
6. Have a Yamaha dealer adjust the headlight beam if necessary.


PERIODIC MAINTENANCE AND MINOR REPAIR



EAM0037

Replacing the brake/taillight bulb

1. Remove the brake/taillight lens by removing the screws.
2. Remove the brake/taillight bulb holder by turning it 1/4 turn counter-clockwise.
3. Remove the defective bulb.
4. Place a new bulb into position, and then secure it with the bulb holder.
5. Place the brake/taillight lens in the original position, and then install the screw.



EAU03497

Replacing a turn signal light bulb

1. Remove the turn signal light lens by removing the screw.
2. Remove the defective bulb by pushing it in and turning it counterclockwise.
3. Insert a new bulb into the socket, push it in, and then turn it clockwise until it stops.
4. Install the lens by installing the screw.

ECA00065

CAUTION:

Do not overtighten the screw, otherwise the lens may break.

EAU01008

Troubleshooting

Although Yamaha scooters receive a thorough inspection before shipment from the factory, trouble may occur during operation. Any problem in the fuel, compression, or ignition systems, for example, can cause poor starting and loss of power.

The following troubleshooting chart represents a quick and easy procedure for checking these vital systems yourself. However, should your scooter require any repair, take it to a Yamaha dealer, whose skilled technicians have the necessary tools, experience, and know-how to service the scooter properly.

Use only genuine Yamaha replacement parts. Imitation parts may look like Yamaha parts, but they are often inferior, have a shorter service life and can lead to expensive repair bills.

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU01397


Troubleshooting chart

EW000125


⚠ WARNING

Keep away open flames and do not smoke while checking or working on the fuel system.


1. Fuel




2. Compression



3. Ignition



4. Battery



SCOOTER CARE AND STORAGE

Care 7-1
Storage 7-3

SCOOTER CARE AND STORAGE

Care

While the open design of a scooter reveals the attractiveness of the technology, it also makes it more vulnerable. Rust and corrosion can develop even if high-quality components are used. A rusty exhaust pipe may go unnoticed on a car, however, it detracts from the overall appearance of a scooter. Frequent and proper care does not only comply with the terms of the warranty, but it will also keep your scooter looking good, extend its life and optimize its performance.

Before cleaning

1. Cover the muffler outlet with a plastic bag after the engine has cooled down.
2. Make sure that all caps and covers as well as all electrical couplers and connectors, including the spark plug cap, are tightly installed.

3. Remove extremely stubborn dirt, like oil burnt onto the crankcase, with a degreasing agent and a brush, but never apply such products onto seals, gaskets and wheel axles. Always rinse the dirt and degreaser off with water.

Cleaning

CAUTION:

ECA00011

- **Avoid using strong acidic wheel cleaners, especially on spoked wheels. If such products are used on hard-to-remove dirt, do not leave the cleaner on the affected area any longer than instructed. Also, thoroughly rinse the area off with water, immediately dry it, and then apply a corrosion protection spray.**
- **Improper cleaning can damage windshields, cowlings, panels and other plastic parts. Use only a soft, clean cloth or sponge with mild detergent and water to clean plastic.**

- **Do not use any harsh chemical products on plastic parts. Be sure to avoid using cloths or sponges which have been in contact with strong or abrasive cleaning products, solvent or thinner, fuel (gasoline), rust removers or inhibitors, brake fluid, antifreeze or electrolyte.**
- **Do not use high-pressure washers or steam-jet cleaners since they cause water seepage and deterioration in the following areas: seals (of wheel and swingarm bearings, fork and brakes), electric components (couplers, connectors, instruments, switches and lights), breather hoses and vents.**

SCOOTER CARE AND STORAGE

- **For scooters equipped with a windshield: Do not use strong cleaners or hard sponges as they will cause dulling or scratching. Some cleaning compounds for plastic may leave scratches on the windshield. Test the product on a small hidden part of the windshield to make sure that it does not leave any marks. If the windshield is scratched, use a quality plastic polishing compound after washing.**

After normal use

Remove dirt with warm water, a mild detergent, and a soft, clean sponge, and then rinse thoroughly with clean water. Use a toothbrush or bottlebrush for hard-to-reach areas. Stubborn dirt and insects will come off more easily if the area is covered with a wet cloth for a few minutes before cleaning.

After riding in the rain, near the sea or on salt-sprayed roads

Since sea salt or salt sprayed on the roads during winter are extremely corrosive in combination with water, carry out the following steps after each ride in the rain, near the sea or on salt-sprayed roads.

NOTE : _____

Salt sprayed on roads in the winter may remain well into spring.

1. Clean the scooter with cold water and a mild detergent after the engine has cooled down.

CAUTION: _____

ECA00012

Do not use warm water since it increases the corrosive action of the salt.

2. Apply a corrosion protection spray on all metal, including chrome- and nickel-plated, surfaces to prevent corrosion.

After cleaning

1. Dry the scooter with a chamois or an absorbing cloth.
2. Use a chrome polish to shine chrome, aluminum and stainless-steel parts, including the exhaust system. (Even the thermally induced discoloring of stainless-steel exhaust systems can be removed through polishing.)
3. To prevent corrosion, it is recommended to apply a corrosion protection spray on all metal, including chrome- and nickel-plated, surfaces.
4. Use spray oil as a universal cleaner to remove any remaining dirt.
5. Touch up minor paint damage caused by stones, etc.
6. Wax all painted surfaces.
7. Let the scooter dry completely before storing or covering it.

SCOOTER CARE AND STORAGE

EWA00002

⚠ WARNING

- **Make sure that there is no oil or wax on the brakes or tires. If necessary, clean the brake discs and brake linings with a regular brake disc cleaner or acetone, and wash the tires with warm water and a mild detergent.**
- **Before operating the scooter test its braking performance and cornering behavior.**

ECA00013

CAUTION:

- **Apply spray oil and wax sparingly and make sure to wipe off any excess.**
- **Never apply oil or wax to any rubber and plastic parts, but treat them with a suitable care product.**
- **Avoid using abrasive polishing compounds as they will wear away the paint.**

NOTE :

Consult a Yamaha dealer for advice on what products to use.

Storage

Short-term

Always store your scooter in a cool, dry place and, if necessary, protect it against dust with a porous cover.

CAUTION:

ECA00015

- **Storing the scooter in a poorly ventilated room or covering it with a tarp, while it is still wet, will allow water and humidity to seep in and cause rust.**
- **To prevent corrosion, avoid damp cellars, stables (because of the presence of ammonia) and areas where strong chemicals are stored.**

Long-term

Before storing your scooter for several months:

1. Follow all the instructions in the "Care" section of this chapter.
2. Drain the carburetor float chamber by loosening the drain bolt; this will prevent fuel deposits from building up. Pour the drained fuel into the fuel tank.
3. Fill up the fuel tank and add fuel stabilizer (if available) to prevent the fuel tank from rusting and the fuel from deteriorating.
4. Perform the following steps to protect the cylinder, piston rings, etc. from corrosion.

SCOOTER CARE AND STORAGE

- a. Remove the spark plug cap and spark plug.
 - b. Pour a teaspoonful of engine oil into the spark plug bore.
 - c. Install the spark plug cap onto the spark plug, and then place the spark plug on the cylinder head so that the electrodes are grounded. (This will limit sparking during the next step.)
 - d. Turn the engine over several times with the starter. (This will coat the cylinder wall with oil.)
 - e. Remove the spark plug cap from the spark plug, and then install the spark plug and the spark plug cap.
5. Lubricate all control cables and the pivoting points of all levers and pedals as well as of the sidestand/centerstand.
 6. Check and, if necessary, correct the tire air pressure, and then lift the scooter so that both of its wheels are off the ground. Alternatively, turn the wheels a little every month in order to prevent the tires from becoming degraded in one spot.
 7. Cover the muffler outlet with a plastic bag to prevent moisture from entering it.
 8. Remove the battery and fully charge it. Store it in a cool, dry place and charge it once a month. Do not store the battery in an excessively cold or warm place (less than 0 °C or more than 30 °C). For more information on storing the battery, see page 6-18.

NOTE : _____
Make any necessary repairs before storing the scooter.

⚠ WARNING _____

EWA00003

To prevent damage or injury from sparking, make sure to ground the spark plug electrodes while turning the engine over.

Specifications	8-1
Conversion table	8-4

SPECIFICATIONS

Specifications

Model	YH50
Dimensions:	
Overall length	1.940 mm
Overall width	685 mm
Overall height	1.105 mm
Seat height	765 mm
Wheelbase	1.294 mm
Minimum ground clearance	125 mm
Minimum turning radius	1.800 mm
Weight:	
Wet (with oil and a full fuel tank)	78 kg
Engine:	
Engine type	Air cooled, 2 strokes
Cylinder arrangement	Single cylinder, horizontal
Displacement	49.2 cm ³
Bore x stroke	40.0 x 39.2
Compression ratio	7.25:1
Starting system type	Electric and kick starter
Lubrication system	Separate lubrication (Autolube)
Engine oil:	
Type	Yamalube 2 or 2 strokes engine oil
Classification	Jaso FC ou ISO EG-C, EG-D
Capacity	1.3 L

Transmission oil:	
Type	SAE 10W30 type SE
Capacity	
Périodic oil change	0.11L
Total amount	0.13L
Air filter type:	Wet type element
Fuel:	
Recommended fuel	Regular unleaded gasoline (RON 91 mini)
Fuel tank capacity	7L
Carburetor:	
Type / quantity	PY-12
Manufacturer	GURTNER
Spark plug:	
Type / Manufacturer	BR8HS / NGK
Spark plug gap	0.6—0.7 mm
Clutch type:	Dry, centrifugal automatic
Transmission:	
Primary reduction system	Helical gear
Primary reduction ratio	52/13 (4.000)
Secondary reduction system	Spur gear
Secondary reduction ratio	45/12 (3.750)
Transmission type	V-belt automatic
Operation	Centrifugal automatic type

Chassis:

Frame type	Steel tube underbone
Caster angle ((degree))	25°
Trail	101.3 mm

Tires:

Front:	
Type	Tubeless
Size	2 1/2-16 42M
Manufacturer / Model	MICHELIN / M29S TT
Rear:	
Type	Tubeless
Size	2 3/4-16 46M
Manufacturer / Model	MICHELIN / M29S TT
Maximum load *	182 Kg
Air pressure (cold tire):	
Up to 90 Kg load*	
Front	180 kpa
Rear	190 kpa
90 kg load — maximum load *	
Front	180 kpa
Rear	210 kpa

* Total weight of rider, passenger, cargo and accessories.

Wheels:

Front	
Type	Cast wheel
Size	16 X MT 1.60
Rear	
Type	Cast wheel
Size	16 X MT 1.85

Brakes:

Front	
Type	Single disc brake
Operation	Right hand operation
Type brake fluid	DOT 4
Rear	
Type	Single drum brake
Operation	Left hand operation

Suspension:

Front suspension	Telescopic fork
Rear suspension	Unit swing

Shock absorber:

Front fork type	Coil spring/oil damper
Rear shock absorber assembly type	Coil spring/oil damper

Wheel travel:

Front wheel travel	80 mm
Rear wheel travel	70 mm

SPECIFICATIONS

Electrical:

Ignition system type	C.D.I
Charging system	Flywheel magneto
Battery	
Model	GM4-3B, YB4L-B, FB4L-B
Voltage/capacity	12 V / 4 Ah

Headlight type: Bulb

Bulbs (voltage/wattage x quantity):

Headlight	12V, 35W/35Wx1
Brake/brake light	12V, 5W/21Wx1
Turn signal light	
Front	12V, 10Wx2
Rear	12V, 10Wx2
Meter lights	12V, 1.2Wx2
High beam indicator light	12V, 1.2Wx1
Turn signal indicator light	12V, 1.2Wx1
Oil warning light	12V, 2Wx1

Fuses:

Main fuse	7.5 A
-----------	-------

Conversion table

All specification data in this manual are listed in SI and METRIC UNITS.

Use this table to convert METRIC unit values to IMPERIAL unit values.

Example:

METRIC VALUE	CONVERSION FACTOR		IMPERIAL VALUE
2 mm	0.03937	=	0.08 in

Conversion table

METRIC SYSTEM TO IMPERIAL SYSTEM			
	Metric unit	Conversion factor	Imperial unit
Torque	m•kgf	7.233	ft•lbf
	m•kgf	86.794	in•lbf
	cm•kgf	0.0723	ft•lbf
	cm•kgf	0.8679	in•lbf
Weight	kg	2.205	lb
	g	0.03527	oz
Speed	km/h	0.6214	mi/h
Distance	km	0.6214	mi
	m	3.281	ft
	m	1.094	yd
	cm	0.3937	in
	mm	0.03937	in
Volume, Capacity	cc (cm ³)	0.03527	oz (IMP liq.)
	cc (cm ³)	0.06102	cu•in
	L (liter)	0.8799	qt (IMP liq.)
	L (liter)	0.2199	gal (IMP liq.)
Miscellaneous	kg/mm	55.997	lb/in
	kgf/cm ²	14.2234	psi (lbf/in ²)
	°C	1.8 + 32	°F

CONSUMER INFORMATION

Identification numbers 9-1
Key identification number 9-1
Vehicle identification number 9-1
Model label 9-2

CONSUMER INFORMATION

Identification numbers


EAU02944

Record the key identification number, vehicle identification number and model label information in the spaces provided below for assistance when ordering spare parts from a Yamaha dealer or for reference in case the vehicle is stolen.

1. KEY IDENTIFICATION NUMBER:

2. VEHICLE IDENTIFICATION NUMBER:

3. MODEL LABEL INFORMATION:




1. Key identification number

EAU01041

Key identification number

The key identification number is stamped into the key tag.

Record this number in the space provided and use it for reference when ordering a new key.



1. Vehicle identification number


EAU01044

Vehicle identification number

The vehicle identification number is stamped into the frame.

NOTE : _____

The vehicle identification number is used to identify your scooter and may be used to register your scooter with the licensing authority in your area.



1. Model label

EAU01278

Model label

The model label is affixed to the bottom of the seat. (See page 3-8 for seat opening procedures.) Record the information on this label in the space provided. This information will be needed when ordering spare parts from a Yamaha dealer.

CONSUMER INFORMATION

EAU01052*

YOU ARE HEREBY REMINDED THAT MODIFICATIONS TO THE ENGINE OR THE POWER OF THE SCOOTER ARE FORBIDDEN BY LAW.

ANY CHANGES FOR THE PURPOSE OF RAISING THE TOP SPEED OF THE VEHICLE OR BOOSTING THE POWER OF THE ENGINE WOULD LEAD TO THE SCOOTER BEING CLASSED AS A SCOOTER.

THIS WOULD REQUIRE THE OWNER:

- TO OBTAIN A NEW TYPE APPROVAL
- TO OBTAIN A SCOOTER REGISTRATION LICENSE
- TO HOLD A DRIVING LICENSE

IN ADDITION, SUCH CHANGES WOULD LEAD TO THE INVALIDATION OF TIE INSURANCE COVER, SINCE INSURANCE POLICIES EXPLICITLY FORBID TECHNICAL CHANGES WHICH HAVE THE PURPOSE OF BOOSTING THE PERFORMANCE.

FOR THE REASONS SET OUT ABOVE, A BREACH OF THE PROHIBITION TO TAMPER WITH THE ENGINE IS PUNISHED BY LAW BY APPROPRIATE FINES INCLUDING THE CONFISCATION OF THE VEHICLE.

FINES ARE ALSO INFLICTED, ACCORDING TO CIRCUMSTANCES, FOR DRIVING WITHOUT A HELMET AND A LICENSE PLATE, AS WELL AS FOR TAX EVASION (OMITTING TO PAY OWNERSHIP TAX).

DRIVING WITHOUT A DRIVING LICENSE IS A CRIMINAL OFFENSE.



PRINTED IN FRANCE
2003.01 (E)