




# **SERVICE INFORMATION**

Sales division  
Technical network leadership












SUBJECT: SUMMARY OF EMISSION CONTROL SYSTEMS - EURO2 STANDARDS.

## **PULSAIR SYSTEM**


	1	2	3	4	5	6
<b>103</b>						
<b>Ludix R 25 km/h version</b>						
<b>Ludix R 45 km/h version</b>						

1. Pulsair reed valve
2. Primary filter
3. Air filter
4. Insulating foam
5. Oil pump control unit
6. Electric oil pump

	Dealership	Spare parts	Mechanic 1	Mechanic 2	Mechanic 3
<b>SIGN ATUR</b>					


















	1	2	3	4	5	6
<b>Looxor 50 cc</b> <b>25 km/h version</b> <b>Looxor 100 cc</b>						
<b>Speedfight2 50 cc</b> <b>TKR 50 cc</b> <b>Vivacity 50 cc</b> <b>45 km/h version</b> <b>Speedfight2 100 cc</b> <b>Vivacity 100 cc</b>						
<b>XP6 - XPS - XR6</b>						

1. Pulsair reed valve
2. Primary filter
3. Air filter
4. Insulating foam
5. Oil pump control unit
6. Electric oil pump

<b>Looxor 125 cc</b> <b>Looxor 150 cc</b>		Air is drawn in by means of the engine's cooling turbine
--	---	--

	Dealership	Spare parts	Mechanic 1	Mechanic 2	Mechanic 3
<b>SIGN ATUR</b>					





## IAE SYSTEM

	3	4	5	6	7
<b>Ludix</b> <b>Ludix blaster</b> <b>Ludix IL</b>					
<b>Looxor 50 cc</b> <b>Looxor 50 cc IL</b>					
<b>Speedfight2 50 cc</b> <b>TKR 50 cc</b> <b>Vivacity 50 cc</b> <b>45 km/h version</b> <b>Speedfight2 50 cc</b> <b>TKR 50 cc</b> <b>Vivacity 50 cc</b> <b>Version IL</b>					
<b>Jet C-Tech</b>					

1. Pulsair reed valve
2. Primary filter
3. Air filter
4. Insulating foam
5. Oil pump control unit
6. Electric oil pump
7. Air pump

	Dealership	Spare parts	Mechanic 1	Mechanic 2	Mechanic 3
<b>SIGN ATUR</b>					




## LOCATION OF COMPONENTS

<p><b>103</b></p>	<p><b>Ludix IAE 45 km/h version</b>  <b>Ludix IAE Version IL</b>  <b>Ludix Blaster IAE</b></p>
	
<p><b>Ludix R Pulsair</b>  <b>25 km/h version</b></p>	<p><b>Ludix R Pulsair</b>  <b>45 km/h version</b></p>
	

1. Pulsair reed valve
2. Primary filter
3. Air filter
4. Insulating foam

5. Oil pump control unit
6. Electric oil pump
7. Air pump





	Dealership	Spare parts	Mechanic 1	Mechanic 2	Mechanic 3
<b>SIGN ATUR</b>					

<b>Looxor 50 cc 25 km/h version</b> <b>Looxor 100 cc Pulsair</b>	<b>Looxor 50 cc IAE 45 km/h version</b> <b>Looxor 50 cc IAE Version IL</b>
 <p>Diagram showing the installation of parts 1, 2, and 3 on the Looxor 50 cc 25 km/h version and Looxor 100 cc Pulsair. Part 1 is the Pulsair reed valve, part 2 is the primary filter, and part 3 is the air filter.</p>	 <p>Diagram showing the installation of parts 3, 5, 6, and 7 on the Looxor 50 cc IAE 45 km/h version and Looxor 50 cc IAE Version IL. Part 3 is the air filter, part 5 is the oil pump control unit, part 6 is the electric oil pump, and part 7 is the air pump.</p>
<b>Looxor 125 cc Pulsair</b> <b>Looxor 150 cc Pulsair</b>	
 <p>Diagram showing the installation of part 1 on the Looxor 125 cc Pulsair and Looxor 150 cc Pulsair. Part 1 is the Pulsair reed valve.</p>	

1. Pulsair reed valve
2. Primary filter
3. Air filter
4. Insulating foam

5. Oil pump control unit
6. Electric oil pump
7. Air pump

	Dealership	Spare parts	Mechanic 1	Mechanic 2	Mechanic 3
<b>SIGN ATUR</b>					

<b>Speedfight2 50 cc</b> <b>TKR 50 cc</b> <b>Vivacity 50 cc Pulsair</b> <b>25 km/h version</b> <b>Speedfight2 - Vivacity 100 cc Pulsair</b>	<b>Speedfight2 50 cc</b> <b>TKR 50 cc</b> <b>Vivacity 50 cc IAE</b> <b>45 km/h version Version IL</b>
	
<b>Jet C-Tech IAE</b>	<b>XP6 - XPS - XR6 Pulsair</b>
	





1. Pulsair reed valve
2. Primary filter
3. Air filter
4. Insulating foam

5. Oil pump control unit
6. Electric oil pump
7. Air pump

	Dealership	Spare parts	Mechanic 1	Mechanic 2	Mechanic 3
<b>SIGN ATUR</b>					

SERVICE OPERATIONS

The filter elements such as the filter foam, the primary filter and the air filter are replaced once every 10000 kms.



	Dealership	Spare parts	Mechanic 1	Mechanic 2	Mechanic 3
SIGN ATUR					