




SALES DIVISION
NETWORK TECHNICAL INFORMATION

SERVICE INFORMATION




METAL-X AND SPEEDFIGHT FURIOUS 2

Subject: ELECTRONIC INSTRUMENT PANEL

This instrument panel is fully electric and electronic.

The instrument panel:


- 1 . Fuel low warning light
- 2 . Flasher warning light
- 3 . Headlight warning light
- 4 . Oil low warning light
- 5 . Multi-function display




The display unit:

Backlit liquid crystal display

- 6 . Tripmeter (total distance covered)
- 7 . Type of unit used by the tripmeter
- 8 . Type of tripmeter display (total/daily)
- 9 . Fuel gauge
- 10 . Fuel reserve position



	Dealership	Spare parts	Mechanic 1	Mechanic 2	Mechanic 3
Signature					




SERVICE INFORMATION


SALES DIVISION
NETWORK TECHNICAL INFORMATION

The fuel gauge:


The fuel level is shown by lighting of the segments 1 to 8 which represent the fuel level



In the reserve position, the last or last two segments flash and the fuel low level warning light comes on



When the tank is completely empty, the fuel low light stays on, all the segments disappear.



	Dealership	Spare parts	Mechanic 1	Mechanic 2	Mechanic 3
Signature					



SERVICE INFORMATION


SALES DIVISION
NETWORK TECHNICAL INFORMATION

Changing units:

The speed unit can be selected (1) (km/h or mph) by a procedure which uses operating different functions on the machine

This function is available at all times on the vehicle whatever the distance it has covered

This procedure should be completed in under 15 seconds and may be carried out as many times as required without damaging the system



Procedure:

Engine stopped, ignition off

- Set the headlight dip/main switch to the dip position
- Set the flasher switch to the neutral position
- Turn on the ignition and start the engine immediately
- Operate the flashers (right or left), stop them after counting exactly 5 flashes
- Flash the headlight
- Check that the speed unit display is correct
- Stop the engine

	Dealership	Spare parts	Mechanic 1	Mechanic 2	Mechanic 3
Signature					